



8. A well installed softbox with the middle diffuser cloth.

9. Finally, cover the foldable softbox with the front diffuser. And the softbox is ready to use now.



C) Attentions



- 1.Please keep the environment dry and ventilated when using. Do not leave and use the flash in humid or dusty environment.
- 2.Do not touch the diffuser cloth directly by hand which can protect the diffuser cloth from being dirty and infected the function. Putting on gloves is recommended when adjusting the diffuser.
- 3.Open the window/ ventilation hole on the softbox (if any), in order to adjust the high temperature inside. Using softbox under high temperature may lower the durability of the product.
- 4.Please pack the softbox and store it under a cool, dry and good ventilation environment after use.
- 5.Please read this user manual carefully before using this product.



Foldable Softbox Instruction Manual



Thank you for purchasing FalconEyes' products.

For further details of our related products, please contact your local distributor or visit our webpage at www.falconeyes.com.hk Thank you.

Please read this manual carefully before using this product.

E-mail: info@falconeyes.com.hk

Website: www.falconeyes.com.hk

FM1305_SOFTBOX_ENG

Features

This Foldable softbox is a new designed model with Utility Model Patent Certificate. The patent no is 20112036744.3. The new foldable softbox has inherited the full function from tradition softbox and has succeeded on fast set up and closing. Users no longer need to be suffering from difficult and time consuming set up. The new foldable softbox can be set up within 60 seconds which can save your valuable time and make your job more efficient. The foldable softbox is a superior accessory that a professional photographer must have.

3.

Install the foldable softbox onto the studio flash as per the direction of the arrow, and then turn it clockwise to lock it on the studio flash.




4. Release the velcro tape, when the foldable softbox is installed onto the studio flash firmly. As shown in the figure on the right.



Operations

1. The foldable softbox is packed compactly in a carrying bag.



The Velcro helps to tighten the size of

5. Open the softbox, and then press down the connecting rod in an inward direction as shown by the arrow.



6. A completely opened softbox.

2. Figure on the right is a foldable softbox with Velcro set up.

