### **D)** Specification

| Model No.            | LHD-B455                                      |
|----------------------|---|
| Power                | Light bulb, 4x55W                             |
| Colour Temperature   | 5300K—5500K                                   |
| Voltage              | AC220-240V50Hz / AC110-120V60Hz               |
| Weight               | 0.5kg   |
| Softbox size         | 70cm (octagon)                                |
| Dimension            | 13 x12.5 x 19cm (Lamp holder only)            |
| Accessories Included | Lamp holder, Softbox ,Diffuser,Fiber Rod x 10 |
| Optional Accessories | Light Bulb                                    |

# E) Attentions 🛕

- Please use the appropriate voltage labeled on the product.
- Do not remove the light bulb when the power is on.
- Do not remove the light bulb until the light is switched off for at least 15 minutes.
- Please contact the distributor once the light bulb goes out. Users can also use different power light bulb with power not higher than 55W
- Make sure the device is at least 0.5M distance from the flammable object.
- When installing the light bulb. Please note whether the voltage of the light bulb is consistent to the voltage of the light.



• Please leave the cooling window open to avoid overheating if using the product for a long period of time.



LHD-B455 Fluorescent Light Instruction Manual



Thank you for purchasing FalconEyes' products.

For further details of our related products, please contact your local distributor or visit our webpage at www.falconeyes.com.hk Thank you.

Please read this manual carefully before using this product. Falcon Eyes Limited

#### A) Features

LHD-B455 series utilizes four pieces of spiral fluorescent bulbs to illuminate the area with powerful cool light but in quiet.

With the cool lighting, photographers can work in a more comfortable environment; the light can be put near the shooting object without damaging it.

It provides perfect projection angle to cover a studio. It is designed with 2 power switches to control the light output. A softbox is included for softening the light.

## **B) Major Parts**




- a. Individual Switches
- h. Power Cable
- c. Stand Fixing Screw
- d. Fuse Holder
- e. Angle Lock Screw
- f. Fiber Rod
- g. Cooling Window
- h. Fluorescent Bulb

# C) Instructions



First, place the lamp holder and the power cord through the hole in the middle of the softbox, and then insert the eight fiber rods into the holes of the lamp holder.



Insert the rods into the four flexible holders of the soft box, and then insert the rest of the rods to the other holders of the soft box.



3 Using the velcro to tighten the soft box when all the rods are well inserted.



4 Install with the light bulbs as well as the diffuser.

-1